



CUSTOMER SERVICES: 819 791.8448 SALES: 819 943.0900

REXROTH LINE
(OTHER PARTS AND COMPLETE PUMPS
NOT LISTED ARE AVAILABLE)

A8VO80			
	<i>PART #</i>	<i>DESCRIPTION</i>	<i>USED IN PUMP #</i>
	R425758	PINION GEAR	A8VO08
	R415312	VALVE PLATE RH	A6VM80
	R425759	DRIVE SHAFT	A6VE80
	R419657	VALVE PLATE LH	A7VO80
	R421289	CYLINDER BLOCK	
	R408762	CENTER PIN	
	R443339	PISTON	
	R831893	PISTON RING	
	R062847	RETAINER PLATE	
	R831106	SCREW	
	R036642	GEAR	
	R422707	STUB SHAFT	
	R408894	CUP SPRING	
	R412411	SPRING COLLAR	
	R412412	SPRING COLLAR	
	R412413	SPRING COLLAR	
	R412414	SPRING COLLAR	
	R412415	SPRING COLLAR	
	R412416	SPRING COLLAR	
	R412417	SPRING COLLAR	

A8VO107			
	<i>PART #</i>	<i>DESCRIPTION</i>	<i>USED IN PUMP #</i>
	R425724	DRIVEN SHAFT	A8VO107
	R425723	DRIVE SHAFT (24 SPLINES)	
	R430673	DRIVE SHAFT (20 SPLINES)	A7VO107
	R430886	CYLINDER BLOCK	
	R650453	VALVE PLATE RH	410390

	R650454	VALVE PLATE LH	442734
	R410289	CENTER PIN	
	R443469	PISTON	
	R831895	PISTON RING	
	R409134	CUP SPRING	
	R024999	RETAINER PLATE	
	R831106	SCREW	
	R416253	IDLER GEAR	
	R412570	SPRING COLLAR	
	R412571	SPRING COLLAR	
	R412572	SPRING COLLAR	
	R412573	SPRING COLLAR	
	R412574	SPRING COLLAR	
	R412575	SPRING COLLAR	
	R412576	SPRING COLLAR	
	R422411	STUB SHAFT	
	R157352	SHAFT KEY	

A6VM107			
	<i>PART #</i>	<i>DESCRIPTION</i>	<i>USED IN PUMP #</i>
	R117723	DRIVE SHAFT	A6VE107
	R921430	DRIVE SHAFT	
	R421288	CYLINDER BLOCK	
	R921788	VALVE PLATE M	
	R921524	CENTER PIN	
	R443470	PISTON	
	R831895	PISTON RING	
	R921541	CUP SPRING	
	R024999	RETAINER PLATE	
	R602493	SCREW	
	R921535	SPRING COLLAR	
	R921536	SPRING COLLAR	
	R921537	SPRING COLLAR	
	R921538	SPRING COLLAR	
	R921539	SPRING COLLAR	
	R921540	SPRING COLLAR	

A8VO160			
	<i>PART #</i>	<i>DESCRIPTION</i>	<i>USED IN PUMP #</i>
	R436474	DRIVE SHAFT LH	A8VO160
	R436475	DRIVE SHAFT RH	A7VO160
	R430794	CYLINDER BLOCK	A6VE160
	R650455	VALVE PLATE RH	A6VM160
	R650456	VALVE PLATE LH	410209
	R418497	CENTER PIN	9437336

	R430790	PISTON	9437337
	R831897	PISTON RING	
	R410551	CUP SPRING	
	R062969	RETAINER PLATE	
	R153648	SCREW	
	R036640	IDLER GEAR	
	R414031	SPRING COLLAR 9,75	
	R414032	SPRING COLLAR 9,85	
	R414033	SPRING COLLAR 9,95	
	R414034	SPRING COLLAR 10,05	
	R414035	SPRING COLLAR 10,15	
	R414036	SPRING COLLAR 10,25	
	R414037	SPRING COLLAR 10,35	
	R432293	SPRING COLLAR 10,45	
	R432294	SPRING COLLAR 10,55	
	R436640	STUB SHAFT	
	R830361	SHAFT KEY	

A8VO200			
	<i>PART #</i>	<i>DESCRIPTION</i>	<i>USED IN PUMP #</i>
	R077316	DRIVE SHAFT LH	A8VO200
	R075457	DRIVE SHAFT RH	A7VO200
	R042247	CYLINDER BLOCK	A6VE200
	R050516	VALVE PLATE RH	A6VM200
	R050517	VALVE PLATE LH	
	R080908	CENTER PIN	
	R031949	PISTON	
	R031949-A	PISTON RING	
	R418513	CUP SPRING	
	R033027	RETAINER PLATE	
	R602395	SCREW	
	R045069	SPRING COLLAR	
	R073946	SPRING COLLAR	
	R045070	SPRING COLLAR	
	R073947	SPRING COLLAR	
	R045071	SPRING COLLAR	
	R073948	SPRING COLLAR	
	R073949	SPRING COLLAR	
	R101944	SPRING COLLAR	

A10VS071			
	<i>PART #</i>	<i>DESCRIPTION</i>	<i>USED IN PUMP #</i>
	R924554	PISTON (9) & SHOE ASSY.	A10VS071
	R907126	CYLINDER BLOCK	
	R936641	VALVE PLATE RH	

	R936640	VALVE PLATE LH
	R941714	RETAINER PLATE
	R939847	BALL GUIDE
	R720178	SPRING
	R939848	PRESS PIN (3)
	R720186	SNAP RING

A10VSO28			
	<i>PART #</i>	<i>DESCRIPTION</i>	<i>USED IN PUMP #</i>
	R925459	PISTON (9) & SHOE ASSY.	A10VSO28
	R907125	CYLINDER BLOCK	
	R936648	VALVE PLATE RH	
	R936647	VALVE PLATE LH	
	R942514	RETAINER PLATE	
	R944743	BALL GUIDE	
	R924891	SPRING	
	R785407	PRESS PIN (3)	
	R939048	SNAP RING	

A10VSO45			
	<i>PART #</i>	<i>DESCRIPTION</i>	<i>USED IN PUMP #</i>
	R925466	PISTON (9) & SHOE ASSY.	A10VSO45
	R907001	CYLINDER BLOCK	
	R936645	VALVE PLATE RH	
	R936644	VALVE PLATE LH	
	R943627	RETAINER PLATE	
	R941318	BALL GUIDE	
	R071072	SPRING	
	R941277	PRESS PIN (3)	
	R939056	SNAP RING	

A10VSO100			
	<i>PART #</i>	<i>DESCRIPTION</i>	<i>USED IN PUMP #</i>
	R925463	PISTON (9) & SHOE ASSY.	A10VSO100
	R906882	CYLINDER BLOCK	
	R936661	VALVE PLATE RH	
	R936639	VALVE PLATE LH	
	R967136	RETAINER PLATE	
	R944744	BALL GUIDE	
	R906894	SPRING	
	R906879	PRESS PIN (3)	
	R906880	SNAP RING	

A4VG71

	<i>PART #</i>	<i>DESCRIPTION</i>	<i>USED IN PUMP #</i>
	R416736	PISTON (9) & SHOE ASSY.	A4VG71
	R443972	CYLINDER BLOCK	
	R087277	VALVE PLATE RH	
	R650709	VALVE PLATE LH	
	R921904	RETAINER PLATE	
	R921905	BALL GUIDE	
	R443361	SWASH PLATE	